

Student Instructions for Axle Installation

MATERIALS NEEDED FROM STUDENT KIT:

Coropast (for chassis or car body)

4 Eye hooks

2 Wooden bars

1 Push pin

Instructions:

1. Use push pin to mark where you want the wooden bars on the coropast.
2. Poke a hole where you will screw in the eyehooks.
3. Set one of the wooden bars on the topside of the car body on top of where you poked the holes.
4. On the underside of the car body, push the eye hook into the hole and screw it into the wooden bar.
5. Repeat with the second wooden bar.